

TRACTORS POWER STEERING CONVERSION KIT WITH BY-PASS SYSTEM INSTALLING INSTRUCTION

POWER STEERING CONVERSION KIT WITH BY-PASS AND SECURITY VALVE FOR FIAT 780 TRACTORS MOUNTING INSTRUCTIONS

1. Oil reservoir.
2. Hydraulic steering oil pump.
3. Bracket to engine body (Spacer should be used between engine and bracket)
4. Assemble valf and piston.
5. 5/8 R6 Hose from reservoir to oil pump fasten hose clamps.
6. Return hose from lift to reservoir 3/8 R6.
7. Pressure hose 5/16 R1 from oil pump to lift.
8. Assemble the long rod.
- 9 After the center the valve shaft and fasten with M8 bolts.
10. Use special sae 10 or 20 oil (1lt) start engine, check fastening bolts and hoses after a week.
11. The adjusting screw of the pressure valve.

FIAT 780

